



INSTRUCTION MANUAL

DIGITAL TIME VALVE



CONTROL BUTTONS




INSTALLING THE BATTERY



- Remove the battery cover-keep battery compartment dry-install the battery by lining up the connections.
- Place the battery inside the compartment and reinstall the battery cover. Then Recharge the battery


NOTE: When battery is first connected, Press Recharge the battery before use




HOW TO INSTALL

Attach the timer inlet to the outdoor faucet/spigot turning clockwise-hand tighten only. The timer needs to be kept upright for waterproofing. From the timer outlet connect a drop irrigation system or a garden hose. It can also be used for a blowdown valve of water purification system.

Maximum operation pressure:85PSI(0.6Mpa)



MAINTENANCE




- Remove filter core cover and clean the filter core every 8-12 months.
- Remove battery if timer is not used for an extended time.
- In freezing conditions, un-install the timer and bring it indoors to prevent damage

SETTING - TIME & DAY



Set the current time


Push **SET** to select hours, then again to set minutes. Adjust using **-** **+** AM/PM is set by increasing or decreasing the hour.



Set the current day

Push **SET** until the square flashes under the day of the week Set the day of the week using **-** **+**


SETTING - WATERING DURATION



Push **MODE** and select Duration

Adjust minutes using **-** **+** or push **SET** to adjust seconds

SETTING - WATERING DAY(S)




Push **MODE** and select Days.

Push **SET** until the square flashes under Monday.

Push **-** to deactivate Monday or **+** to keep it active and advance to Tuesday. Do this for each day you would like to water


SETTING - START TIMES



Push **MODE** and select Starts(start time)

Adjust hours using **-** **+** or push **SET** to adjust minutes You can set up to 9 start times.



MANUAL OPERATION



To instantly water push **ON**

Push **OFF** to stop or it will run for the programmed time(if set) Default watering time is 1 minutes

DELAY WATERING



Used to shut-down time in winter or when it is not needed. Set schedules will be retained. You must turn this feature off to resume programmed watering schedules.

Push and hold **OFF** for 3 seconds until the symbol appears on the display.

Push and hold **OFF** for 3 seconds and the symbol will disappear and the previously programmed watering schedules will resume.